




Floor Burnisher User's Guide



B-20

Dear Customer:

Congratulations on the purchase of your new floor burnisher. As you are already aware, the scene of the detailing world is becoming more high tech, and we at Mytee Products, Inc. strive to keep you on the cutting edge with superior quality and technology.

Keep in mind that your floor burnisher is a machine and neglect and abuse will cause unnecessary damage and void warranty. With simple maintenance however, your vacuum will give you quality performance for many years to come.

The labels on your unit are scratch resistant. They are made with a clear film. To achieve a high gloss finish, simply peel off the thin, clear layer.

If warranty questions arise, please consult your user's guide or get in touch with your distributor. If you have questions about maintenance, replacing parts or ordering parts, please call an authorized Mytee Products, Inc. service center. To see an updated list, visit our website at www.Mytee.com.

Before you begin cleaning, please read you user's guide thoroughly.

Sincerely,
Customer Care Dept.

IMPORTANT INFORMATION

Model # _____ Serial # _____

Distributor name and phone# _____

Date of purchase _____

Table of Contents

General Safety	3
Grounding Instructions/ Maintenance	5
Maintenance Instructions (ASC)	6
Warranty	7
RMA	8

General Safety/ Warnings

These precautions have been written for your safety and the safety of others in mind. These precautions **MUST BE FOLLOWED** at all times to avoid serious injury, harm, and/or death, and damage to the unit.

Warning: To reduce the risk of fire, electrical shock, or injury:

1. READ ALL INSTRUCTIONS BEFORE USING EXTRACTORS.
2. Use only as described in this manual. Use only manufacturer's recommended attachments.
3. Always unplug power cord from electrical outlet before attempting any adjustments or repairs.
4. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
5. Do not pull or carry by cord. Do not close a door on cord or pull cord around sharp edges or corners.
6. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not use with damaged cord or plug. If the unit is not working, as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to an Authorized Service Center
8. Do not use outdoors or on wet surfaces and/or standing water.
9. Always unplug or disconnect the appliance from the power supply before servicing. Unplug or disconnect the appliance from power supply when not in use.
10. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
11. Do not use in areas where flammable or combustible material may be present.
12. Do not leave the unit exposed to harsh weather elements. Temperatures below freezing may damage components and void warranty.
13. Use only the appropriate handles to move and lift unit. Do not use any other parts of this machine for this purpose.
14. Keep hair, loose clothing, fingers, and all parts of body away from all openings and moving parts.
15. Use extra care when cleaning on stairs
16. To reduce the risk of fire or electric shock, do not use this machine with a solid-state speed control device.
17. Risk of explosion. Floor sanding can result in an explosive mixture of fine dust and air. Mytee floor machines are NOT intended for floor sanding operations.

18. Risk of fire. The motor of this machine creates spark, which could ignite volatile substances. Use ONLY commercially available floor cleaners and waxes intended for machine application.
19. If the switch lever is actuated accidentally, the motors high starting torque will cause the machine to move and the handle to whip, which may cause injury or damage.
20. Never use the machine with thin pads. Use a pad at least 1” thick.
21. DO NOT continue to use a pad that is clogged with dirt. It wil labor the motor heavily. Change the pad frequently.
22. DO NOT allow the machine to sit in one position when it is turned on. Floor damage will occur.
23. Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified service person if you are in doubt as to whether tht outlet is properly grounded. Do not modify the plug provided with the appliance– if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

Grounding Instuctions

This appliance must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

This appliance is for use on a nominal 120-volt circuit and has a ground plug. Make sure that the appliance is connected to an outlet having the same configuration as the plug. No adapter should be used with this appliance.

Maintenance

Wipe the surface of the machine with a damp cloth. Clean cable with a damp cloth before wrapping around cord hooks located on back handle.

Maintenance Instructions

FOR AUTHORIZED PERSONNEL ONLY

Fuse Blowing

If your floor machine blows fuses when starting, then your wall electric power line is overloaded, underfused, or undersized. Make sure that the capacity of the fuse corresponds to the capacity of the power line. If your machine has been in use for any length of time and suddenly starts to blow fuses, check your wiring very carefully at the weitch box and at the wall plug. Also be sure to check the connection at the strain relief attachment at the switch box. Check all phases of the above instructions and if you fail to find the trouble, call you Mytee Authorized Service Center to have them check the capacitor for failure.

- Check your wall plug and make sure you have power.
- Check your machine cord plug and make srue it is inserted to its full depth into the wall plug.
- Check machine itself. If the machin is plugged in, the power is turned on, but the machine still fails to start, disconnect the motor at the base of the handle. Using an extension cord, plug the motor directly into the wall outlet. If the motor starts, then the problem is in the switch or in the cord. Disconnect the plug, open switch box, and examine switch contacts and reminals carefully.
- If you are certain that these reminals are secured and switch contacts are functioning, the trouble is most likely located in the cord. In this case, contact your Mytee Authorized Service Representative to arrange for proper servicing of the machine.

“Hot” Wire

If electric cable becomes “hot”, you either have an insufficient power supply or are using too small a gauge extension cord. The extension cord must be one gauge larger than the machine cable.

MYTEE LIMITED WARRANTY POLICY

Mytee Products, Inc. endeavors to provide high quality products and product support to its customers and therefore backs up all of its new products purchased from Mytee Products Inc. (“Mytee”) or any authorized Mytee distributor/service center with this limited warranty. This limited warranty begins on the date of the customer’s purchase and is valid and available to the original purchaser only. Mytee’s products are for commercial use only and are not intended for personal, family or household uses.

HOWEVER, OTHER THAN SET FORTH HEREIN, MYTEE GIVES NO WARRANTY, EXPRESS OR IMPLIED, AS TO DESCRIPTION, QUALITY, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, PRODUCTIVENESS, INFRINGEMENT, OR OTHER MATTER, OF ANY GOODS WHICH MYTEE SHALL SUPPLY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. MYTEE SHALL IN NO WAY BE RESPONSIBLE FOR THE PROPER USE AND APPLICATION OF THE GOODS. MYTEE NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR MYTEE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF MYTEE’S GOODS. THIS LIMITED WARRANTY POLICY MAY BE CHANGED OR WITHDRAWN BY MYTEE AT ANY TIME WITHOUT NOTICE.

WEAR PARTS 90-DAY LIMITED WARRANTY: Mytee will replace all wear parts for 90 days from the date of original purchase. “Wear parts” are items which wear out as a result of usage or the passage of time and are consumed despite attempts to maintain them, such as gaskets, wheels, brass, cords, wires, electrical terminals, hoses, switches, thermostats, plastisol parts, filters, bearings, brushes, solenoids, o-rings, bulbs, heating elements, castors, or other parts deemed wear items in Mytee’s sole discretion. This warranty covers the cost of replacement only and does not cover shipping or labor costs.

PUMP, VACUUM MOTOR AND HEATER 1-YEAR LIMITED WARRANTY: Mytee warrants that pumps, vacuum motors, and heaters will be free from manufacturing defects, defects in workmanship, and defects in material for one (1) year from the date of original purchase. This warranty does not apply and is void if the pump, vacuum motor, or heater has worn brush motors, water damage, chemical build-up, chemical damage, or evidence of abuse, neglect or tampering. This warranty covers the cost of replacement or repair only and does not cover shipping or labor costs.

HOUSING 3-YEAR LIMITED WARRANTY: For three (3) years from the date of purchase, Mytee warrants a percentage of the cost of replacement of rotationally-molded housings pro-rated as follows: Mytee will pay 100% of replacement cost in the first year from the date of purchase, 75% of replacement cost in the second year from the date of purchase and 25% in the third year from the date of purchase. Replacement cost does not include the cost of shipping or labor.

LIMITATION OF DAMAGES: THE REMEDY OF REPLACEMENT OR REPAIR OF ANY DEFECTIVE GOODS SHALL BE THE EXCLUSIVE REMEDY UNDER ANY WARRANTY MADE BY MYTEE, WHETHER EXPRESS OR IMPLIED. IN NO EVENT SHALL MYTEE BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, PROPERTY DAMAGES, OR PERSONAL INJURIES.

All limited warranties are void for, and Mytee does not warrant in any way, any product that evidences misapplication, improper installation, abuse, lack of maintenance, negligence in use or care, abnormal use, alteration of design, use of incompatible or corrosive chemicals, use in a rental service, and/or servicing, installation of parts, or repairs by anyone other than Mytee or a Mytee authorized distributor or service center. Mytee may make changes in products it manufactures and

markets at any time; these changes are made without obligation to change, retrofit, or upgrade any product previously sold or manufactured.

Mytee has no obligation to honor the limited warranties set forth herein unless the original purchaser, promptly upon discovering the warranty claim and prior to continuing to use the product, contacts Mytee or a Mytee authorized distributor or service center to describe the claim and to receive and follow instructions for documenting and resolving the claim. In addition, the purchaser must provide the product to which the claim applies to Mytee or a Mytee authorized distributor or service center for a thorough inspection.

If any provision or portion of this limited warranty policy is found to be unenforceable, then the remaining provisions and portions shall remain valid and enforceable. If any provision or portion of this limited warranty policy is found to be limited by law, then that provision or portion shall be construed to make it effective within the bounds of law. For example, if there are legal limitations on the duration of warranties, the warranties made herein shall be construed to have the minimum duration required by law, or, if there are legal limitations of exclusion of remedies, the exclusions made herein shall be construed to apply to the fullest extent possible without violating the law.

The validity, construction and performance of this warranty policy shall be governed by the laws of the State of California, without respect to conflicts of laws principles. The exclusive jurisdiction of any legal action arising from or related to this warranty policy shall be in the State of California and no legal action shall be commenced elsewhere.

RETURNED MATERIAL AUTHORIZATION PROCEDURE

It is the responsibility of any Authorized Service Center (ASC) or Distributor with written authorization to ensure the Customers equipment is repaired as soon as possible. Only Mytee Products, Inc. or it's authorized dealers with written authorization, service centers, and agents may make warranty repairs on these products. All others do so at their own risk and expense.

The Distributor must follow Mytee Products, Inc. standard RMA procedure:

1. When a repair falls within the Warranty time period for a piece of equipment, the Distributor will fill out a RMA/Warranty claim form. This form will act as a repair order to replace any defective parts.
2. All defective parts must be returned to Mytee Products, Inc. with the RMA/claim form for evaluation at the customer's expense. **This shipping is non-refundable.** All warranty claims are subject to an evaluation by Mytee Products, Inc. to determine if warranty will be approved. Any credit for repair and/or parts will only be issued upon evaluation and approval from Mytee Products, Inc.
3. When Warranty is approved, the Distributor's account will be credited for the replacement part(s). Mytee Products, Inc. will ship the warranted replacement part(s) to the Distributor prepaid. If Warranty is denied the Distributor's account will not be credited for any parts sent for this claim.